Motion® Tablet PC Quick Reference Guide

for Model T008*

This Quick Reference Guide provides information for using the J3500 Tablet PC.

NOTE: For additional reference information, see the Quick Setup included with your Tablet PC.

Logging on

After turning on your Tablet PC, perform the following steps:



Windows Security button

1. When prompted, press the **Windows Security** button located on the right side of your Tablet PC.
2. Using the pen and the on-screen keyboard, tap in your password.

Getting started

Start > All Programs > Accessories >Tablet PC > Personalize Handwriting Recognition

Motion Documentation

For detailed information about the features of your tablet, go to www.motioncomputing.com/docs. Some documents are available only on the Motion Web site and require an Internet connection. When connected to the Internet, you can save a copy of the document to your tablet hard drive.

Please register your Motion Tablet PC and products at the following Web page: **http://www.motioncomputing.com/prodreg**

Using the pen or touch

Using the Tablet PC pen or touch is similar to using a mouse to make selections and open files. The following table explains the similarities for using a Tablet PC pen, touch, and a mouse. (Touch is an optional feature on the Tablet PC.)

Function	Mouse	Pen	Touch (optional)
Select	Point and click	Point and tap on the display	Tap on the display
Open a file or application	Double-click	Double-tap on the display	Double-tap on the display
Select and drag	Click and drag	Tap and drag on the display	Touch and drag on the display
Display properties or edit functions (cut, copy, paste)	Right-click and hold	Press and hold the pen Function button, then tap the display; or, hold the pen on the display until the swirl appears, then remove the pen tip from the display	Touch and hold your finger on the display until the swirl appears, then remove your finger from the display

Pen and touch tips

- Calibrate the digitizer for better pointer alignment.
  1. Open Motion Dashboard (see the next page).
  2. On the Pen & Tablet panel, select Calibrate Digitizer.
  3. Tap the pen or your finger to the screen, depending on whether you are calibrating for pen or touch.
  4. Follow the instructions on the screen.
- You can change from right- to left-handed usage.
  1. Open Motion Dashboard (see the next page).
  2. On the Pen & Tablet panel, select Pen & Button Options, and then select Tablet and Pen Settings.
  3. In the Settings tab, choose left-handed.
- You can enable a pointer for touch. For more information, see the Dashboard Help.
- Touch also includes touch gestures and flicks. For more information, start Windows Help and search for "touch gestures" and "flicks."
- You can adjust the right-clicking function and enable/disable touch and touch gestures through the Touch Settings window. For more information, see the Dashboard Help.

For more information about using the pen or touch, see the *Tablet PC User Guide.*

Using Tablet PC Input Panel

You can use Tablet PC Input Panel instead of a keyboard to enter text on your tablet.

To open Input Panel, do one of the following:

- Tap at the place you want to enter text, such as a text box. Then tap the floating Tablet PC Input Panel icon.
- Tap the Input Panel tab on the left edge of the screen (default).

You can use the writing pad, the character pad, or the on-screen keyboard to enter text. For more information about using the Input Panel, see the Input Panel Help.

To view the Input Panel Help, tap Tools on the Input Panel, then Help topics.

*See the label on the back of your tablet for the tablet's model number.

Motion Computing, Motion, and Speak Anywhere are registered trademarks of Motion Computing, Inc. in the United States and other countries. All trademarks or registered trademarks are properties of their respective owners.

Copyright © 2010 Motion Computing, Inc.
All rights reserved.
P/N 024-02-0150 Rev. A03

Using the Motion Dashboard to adjust Tablet PC settings

Open the **Motion Dashboard** by pressing this button on the front of the Tablet PC.





Motion Dashboard

Using the Tablet PC buttons



Helpful tip:
For more information about using the secondary functions of the buttons, see the *Tablet PC User Guide* at www.motioncomputing.com/docs.

To activate or deactivate the wireless adapters, open the Motion Dashboard and click the Wireless tab for options.
For more information about button functions, see the *Tablet PC User Guide* at www.motioncomputing.com/docs.

Optimizing battery life

- Use AC power when available. When the Tablet PC is connected to AC power, the battery will continue to charge while using the Tablet PC.
- In the Display panel of the Motion Dashboard, change the setting in "To extend battery life, dim display after:" to the lowest time.
- In the Display panel of the Motion Dashboard, adjust the brightness to the dimmest comfortable brightness level.
- In the Motion Dashboard, set the power button to Sleep or to Hibernate: to conserve battery power, to quickly power on and off, or when not using the Tablet PC.
- When not in use, turn off wireless adapters in Motion Dashboard.

IMPORTANT: The *Tablet PC User Guide*, located at: www.motioncomputing.com/docs, contains information about the following topics.

Setting wireless devices

- To set up and use your Bluetooth wireless devices, see "Using Bluetooth".
- To set up the built-in Wi-Fi adapter, see "Using Wi-Fi (802.11)".
- To set up and use mobile broadband services, see "Using Mobile Broadband".

Using the ports and card slots

For information about the locations and uses for the ports and card slots, see "Features".

Using Motion QuickNav

For information about Motion QuickNav, see "Using Motion QuickNav".

Setting up the Fingerprint Reader

You can use the Fingerprint Reader for user authentication, password replacement, and scrolling (like a touchpad) in applications.

To set up the Fingerprint Reader, see "Using Motion OmniPass™ and Fingerprint Reader".

Using speech recognition

1. For information about configuring speech recognition, see "Using Speech Recognition" in the *Tablet PC User Guide*.
2. Complete the speech recognition tutorial.
   (Start > Control Panel > Speech Recognition > Take Speech Tutorial)